

# SHOWGUN™ Roadcase Upgrade Kit Instructions



Check the contents of this kit. Along with these instructions, it should include:

- One piece foam 2.5" x 5.5" x 14.75"
- One piece foam 1" x 11.75" x 15.24"
- One piece foam 3" x 8" x 11.75"
- Two tubes of adhesive



Remove roadcase lid and door for easy access to interior



Apply adhesive to the 2.5" x 5.5" x 14.75" block in the pattern above to ensure good adhesion.



Press the side of the block with adhesive against the inside of the roadcase at the lower right back corner.



Apply adhesive to the 3" x 8" x 11.75" block in the pattern above to ensure good adhesion.



Press the side of the block with adhesive vertically against the inside of the roadcase in the back left corner between the two existing foam pieces.



Apply adhesive to the 1" x 11.75" x 15.24" block in the pattern above to ensure good adhesion.



Press the side of the block with adhesive inside the roadcase against the front left side.



The adhesive requires 24 hours to fully cure but you can reload it after three hours.

**NOTE:** You can view a video of these assembly instructions at [www.highend.com/support](http://www.highend.com/support)

HIGH END SYSTEMS™



High End Systems Customer Service

2105 Gracy Farms Lane

Austin, TX 78758 USA

voice: 800.890.8989

fax: 512.834.9195

Toll free: 800.890.8989

[www.highend.com/support](http://www.highend.com/support)

p/n 60600280 Version 1