


Road Hog⁴

Display- USB Cable Routing



It was discovered on some Road Hog 4 consoles were assembled with the LCD display USB driver cables routed incorrectly and were causing the connections to come loose from the motherboard.



USB Cables



Correct Routing-

The USB cables should be routed **UNDERNEATH** the power supply cables.

← Power supply cable bundle



Incorrect Routing-

The USB cables are routed **OVER** the power supply cables.