

	<b>Quick Guide</b>	High End Systems	Rev A
	<b>Installing Fixture Libraries on Hog 4 OS Consoles</b>	May 25, 2016	PAGE 1/1

This guide provides the proper steps for installing Hog 4 OS fixture libraries on all consoles in the Hog 4 OS family including Hog 4 PC.

**To install a fixture library:**

1. Download supported fixture library from the web:
  - Latest full fixture library can be found here: (<http://www.highend.com/>)
  - Single fixture libraries can be found here: (<ftp.highend.com/hogsupport/fixturelibraries>)
2. Copy the downloaded fixture library to a USB flash drive.
3. Insert USB flash drive into the console.
4. Navigate to the Hog 4 OS start screen and click on the “file browser“ button.
5. Use the file browser window to drag and drop the fixture library file from the USB flash drive into the libraries directory on the console.
6. The fixture library is now installed.
7. To schedule fixtures from the fixture library you have installed: click
  - Click on the ‘select fixture library’ button in the bottom of the fixture schedule window
  - Chose the fixture library you want to schedule fixtures from
  - Click okay

**NOTE:** When installing a Full Fixture Library you must delete the full fixture library already installed on the console before copying the new full library into the library directory. Failing to do so will result in an error. This is not required when installing individual fixture libraries downloaded from the ftp site.

**Warning:** Upgrading console software removes all manually installed fixture libraries from the console.